

3-1. Using the touch screen

Touch screen (without navigation system)

By touching the screen with your finger, you can control the audio system and air conditioning, adjust the screen display, etc.

Owners of models equipped with a navigation system should refer to the “Navigation System Owner's Manual”.



The “Information” screen shown in the above illustration is displayed when



is pressed.

Button/switch	Page
"CLIMATE"	P. 212, 220
"AUDIO"	P. 238
"INFO" (Displaying the "Information" screen)	P. 196
"DISP" (Adjusting the display)	P. 199
"Telephone"	P. 367
"LEXUS Park Assist"	P. 159
"Screen Setting"	P. 201
"Beep Off"	P. 199
"Adjust Clock"	P. 424

The initial screen



If the engine switch is set to ACC or IG-ON mode, the initial screen will be displayed for a few seconds as the system starts up.

■ To avoid damaging the touch screen

- Touch the screen lightly with your finger. If there is no response, remove your finger from the screen and try again.
- Remove any dirt on the screen by wiping with a soft cloth. Do not use detergent.

■ When using the touch screen

- If the screen is cold, the display may be dark, or the system may seem to be operating slightly slower than normal.
- The screen may seem dark and hard to see when viewed through sunglasses. Change your angle of viewing, or remove your sunglasses.

3-1. Using the touch screen

Setting the touch screen

You can change the touch screen to your desired settings.

Turning off the beep sound

The beep that sounds when a touch screen button is touched can be turned off.

STEP 1 Press .



Touch .


Adjusting the display

STEP 1 Press .

STEP 2 Adjust the display as desired using  /  and  / .


If you do not touch the screen for 20 seconds, the system will return to the previous screen.

► With CD player




3-1. Using the touch screen

► With DVD player




		
Color	Red	Green
		
Tone	Lighter	Darker
Contrast	Weaker	Stronger
Brightness	Darker	Brighter


■ “Day Mode”




When the headlights are turned on, the screen dims. However the screen can be switched to “Day Mode”.

The screen will stay in “Day Mode” when the headlights are turned on until  is touched again.

■ To turn off the picture display

If  is touched, the screen display is turned off, and guidance is by voice only.


■ Opening or closing the rear display (if equipped)



Touching **Rear** opens or closes the rear display.

Screen settings

The following screen settings can be changed.



1 Automatic transition

20 seconds after audio system use, the system will return the display to the previous screen.

2 Switch color

You can select the switch color.

3 Rear system lock (if equipped)

The operation lock on the rear seat entertainment system can be turned on or off.


4 Personal data deletion

The following personal data is deleted:

- User selection settings
- Phone book data
- Dialed numbers and received calls
- Speed dial
- Bluetooth® phone data
- Security code

■ Setting automatic transition

STEP 1 Press  .


STEP 2 Touch  on the "Information" screen.



STEP 3 Touch  or  on the "Screen Setting" screen.

STEP 4 Touch  .

■ Setting the switch color

STEP 1 Press  .


STEP 2 Touch  on the "Information" screen.

STEP 3 Touch  or  on the "Screen Setting" screen.

STEP 4 Touch  .

■ Setting the rear system lock

STEP 1 Press  .


STEP 2 Touch  on the "Information" screen.

STEP 3 Touch  or  on the "Screen Setting" screen.


STEP 4 Touch  .

■ To delete personal data

STEP 1 Press  .

STEP 2 Touch  on the "Information" screen.

STEP 3 Touch  on the "Screen Setting" screen.



Touch  .

Check carefully beforehand, as data cannot be retrieved once deleted.

■ When deleting personal data

Data can only be deleted when the vehicle is stopped.

■ When selling the vehicle

Be sure to initialize both the call history and personal data. (→P. 201)

■ If you touch

The display returns to the previous screen.